



## Substrate Requirements

1. A minimum of  $\frac{3}{4}$  inch T&G plywood must be used and should be glued and screwed in place. Install with adequate slope to insure proper drainage.
2. Make sure that the surface is clean and free of oil, paint, tar or other potential bond breakers.
3. The StoneCraft urethane membrane will cover the entire deck surface as well as 6 inches up the exterior walls and under any exterior doorframes. Make sure that doors are removed and tar paper is lifted 12 inches to provide access for this detail.
4. The plywood surface should extend tightly to the perimeter walls and outer edge.
5. If required, surface drains must be installed flush with the surface of the plywood.
6. Railing may be surface mounted after the StoneCraft system is complete. Pre-drill anchor holes and then fill with silicone or urethane caulking before threading in fasteners. The fastener will displace some of the sealant out of the hole insuring a good seal from the inside out.
7. All flashings are to be installed by StoneCraft.

For further information please contact StoneCraft at 1-800-711-0288.